

http://ww.onassisstyle.com info@onassisstyle.com

# 'The Aphrodite' Professional Flat Iron

### **IMPORTANT SAFEGUARDS**

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

Read all instructions before using. KEEP AWAY FROM WATER.

DANGER – As with most electrical appliances, electrical parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:

- 1. Always "unplug it" immediately after using.
- 2. Do not use while bathing.
- 3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
- 4. Do not place in or drop into water or other liquid.
- 5. If an appliance falls into water, "unplug it" immediately. Do not reach into the water.

### WARNING -To reduce the risk of burns, electrocution, fire, or injury to persons:

- 1. The appliance should never be left unattended when plugged in.
- 2. Close supervision is necessary when this appliance is used by, on or near children or individuals with certain disabilities.
- 3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Onassis Style®.
- 4. Never operate this appliance if it has a damaged cord or plug. If it is not working properly, or if it has been dropped, damaged, or dropped into water return the appliance to Onassis Style® for repair

or replacement (www.onassisstyle.com/support).

- 5. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- 6. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 7. Do not use an extension cord with this appliance.
- 8. This flat iron is hot when in use. Do not let bare skin touch heated surfaces.
- 9. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 10. Children should be supervised to ensure that they do not play with the appliance.
- 11. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.



This appliance is intended for household use.

### **OPERATING INSTRUCTIONS**

This appliance has a polarized plug (one blade is wider than the other). Do not attempt to defect this safety feature. This appliance is provided with a protective device that may make the appliance inoperable under some abnormal conditions. The warranty does not cover faults caused by use contrary to the manufacturer's recommendations.

## **USER MAINTENANCE INSTRUCTIONS**

Untwist cord before use.

This appliance does not require special maintenance or lubrication.

Plates should be cleaned with a damp cloth when cool. Avoid using any chemical containing products (including wet wipes, etc).

After use, allow unit to cool, re package cord and store unit in a safe place.

Do not wrap cord around appliance. Do not hang the unit by the power cord.

**CAUTION:** Care should be used when using this appliance on damaged or color treated hair.

#### TEMPERATURE SETTINGS

**Ideal Styling Temperature** – depends on individual hair and condition. Recommended operating temperature range is 300 – 350 F.

#### **LOWER SETTINGS**

Fine to Normal hair

#### **HIGHER SETTINGS**

Courser and thicker hair.

#### TO USE YOUR FLAT IRON

1. To pre-heat your Flat Iron, plug into an electrical outlet. Turn switch to the "ON" position and select operating temperature via the Digital Temperature Control.

### 1.a Digital Temperature Control and L.E.D Indicator Lights

The Aphrodite professional flat iron has a digital method of displaying the selected heat setting. The temperature settings range from 200, 260, 320, 360, 400, 430 and 450 degrees F. Select your desired temperature via the easy to use up and down arrow buttons. The temperature will light up in bright Blue. If the temperature is actually higher than the setting, then both the set temperature and the actual temperature are highlighted so you know to be careful as the iron may be too hot.

- 2. Always make certain that your hair is completely dry before styling with your iron. Hold ends tight with one hand. Comb through each section to smooth out any tangles. Part off a section of your hair to be straightened.
- 3. Open clamp and grip hair with the flat iron about half an inch from the roots.
- 4. Gently slide the flat iron plates along the section of hair, and at the end carefully release pressure on the handles and let the hair slip out from the plates.
- 5. Repeat as necessary. Do not repeat on the same section of hair for an extended period of time.
- 6. Allow hair to cool off.

## PLATE LOCKING FEATURE AND STORING

- 1. When finished, turn switch to the "OFF" position. Allow iron to cool before storing.
- 2. Re-package the cord and store the unit in a safe place. We recommend storing the unit in the gift box packaging to extend the life of your Aphrodite flat iron.

Do not wrap cord around appliance. Do not hang the unit by the power cord.

Voltage: 120V, 50Hz 35W. Model: IP40M



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the USA and Canada. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

## Warranty Information – 10 Year Manufacturer Warranty

Be sure to register your Aphrodite professional flat iron at www.onassisstyle.com/support

For all warranty information requests, claims and for product registration, please visit; www.onassisstyle.com/support

The manufacturer provides warranty in accordance with the legislation of the customer's own country of residence, with a minimum of 2 years, starting from the date on which the appliance is sold to the end user. A further Warranty period bringing the total Warranty coverage to 10 Years is offered by Onassis Style® for products that are registered online.

The warranty only covers defects in material or workmanship. It does not cover normal wear & tear.

The repairs under warranty may only be carried out by an authorized service centre. When making a claim under the warranty, the original bill of purchase or order number (with purchase date) must be submitted.

The warranty will not apply in cases of:

- Normal wear and tear
- Incorrect use, e.g. overloading of the appliance, use of non-approved accessories
- Use of force, damage caused by external influences
- Damage caused by non-observance of the user manual, e.g. connection to an unsuitable mains supply or non-compliance with the installation instructions
- Partially or completely dismantled appliances